

Luxury Care

Mechanical protection for new & pre-owned luxury vehicles

In a class all their own. Fletcher Jones's Luxury Care extends the warranty on your new or pre-owned luxury vehicle with longer, more comprehensive options.

COVERAGE OPTIONS	Engine	Transmission	Drive Axle	Air Conditioning	Heating & Cooling	Electrical	Braking	Steering	Suspension	Fuel Delivery	All Parts (Exclusionary)
Powertrain Plus New & Preowned											
Preferred New & Preowned											
Maximum New & Preowned											
Upgrades Optional; fees apply	 Seals & Gaskets  Hydraulic Suspension  Air Bladder Suspension										
Deductible Options	\$250 \$500 \$1000										



Additional Benefits *Included in all plans*

- ✓ 24-Hour Roadside Assistance*
 - Towing Service
 - Flat Tire Change
 - Emergency Gas Delivery
 - Battery Jump Service
 - Key Lockout Service
- ✓ Deductible Discount *if returning to selling dealer for covered repair*
- ✓ Substitute Transportation
- ✓ Trip Interruption Service

Luxury Care

Appearance protection plus more for leased vehicles

Eligible Vehicles

- ✓ Acura NSX
- ✓ Audi
- ✓ Aston Martin
- ✓ BMW
- ✓ Bentley
- ✓ Bugatti
- ✓ Cadillac
- ✓ Ferrari
- ✓ Hummer
- ✓ Lamborghini
- ✓ Lotus
- ✓ Maserati
- ✓ Maybach
- ✓ Mercedes
- ✓ Phaeton
- ✓ Porsche
- ✓ Rolls-Royce
- ✓ McLaren

Powertrain Plus

Engine Components: Engine block and cylinder head(s), and all internally lubricated parts, including pistons, pins, rings, connecting rods and bearings, crankshaft and main bearings, camshaft, followers and cam bearings. Push rods, valves, springs, guides, seats, lifters, rocker arms, shafts, bushings, core plugs, timing gear, timing chain or timing belt, belt tensioners and retainers. Eccentric shaft, oil pump, oil cooler and oil cooler lines. Also covered are the following: water pump, oil pan, intake and exhaust manifolds, engine mounts and cushions, engine torque strut, timing cover, valve cover(s), harmonic balancer, flywheel (flex plate) and flywheel ring gear, vacuum pump, dipstick and tube, and all pulleys.

Transmission Components: (Automatic or Manual) Transmission case, transfer case, torque converter, and all internally lubricated parts contained within the cases. Filler tube and dipstick. Vacuum modulator, internal linkage and transmission mounts.

Drive Axle Components: (Front & Rear) Differential housing, trans-axle housing, final drive housing, and all the internally lubricated parts of the foregoing. Axle shafts, constant velocity joints, universal joints, drive shafts, locking hubs, hub bearings, locking rings, supports, retainers and bearings.

Air Conditioning Components: (Factory Installed Units Only) Air conditioner compressor, clutch, clutch pulley, clutch coils, electrical HVAC actuators, condenser, evaporator, expansion valve, accumulator, orifice, idler pulley, bearing, ducts and outlet tubes, blower motor, temperature control programmer, power module, high/low cut off switch and receiver/dryer.

Preferred

Includes Powertrain Plus components plus:

Suspension Components: Upper and lower control arms, control arm shafts and bushings. The upper and lower ball joints, steering knuckles, wheel bearings, stabilizer shaft, linkage and bushings, torsion bars, spindle and spindle supports, radius arm and bushings, coil and leaf springs, strut bar and bushing.

Fuel Delivery Components: Fuel pump, fuel tank, fuel tank sending unit, metal fuel lines, fuel injectors, carburetor, throttle body, fuel distributor, fuel injection pump, diesel injectors, diesel injector pump and vacuum booster pump.

Heating/Cooling Components: Water pump, thermostat, radiator and mounting brackets. Fan shroud and fan controller module. The coolant recovery unit. Heater ducts and cabins. Blower motor, heater core, fan, fan clutch and fan motor.

Electrical Components: Starter, alternator, voltage regulator, distributor, ignition coil, wiring harness, solenoids, ignition switch, lock and tumbler, brake light switch, wiper motors, horn button and horns, driver's side (steering wheel) airbag, manually operated switches, power door locks, window motors and regulators, mirror motors and controls, power antenna motor, power seat motor; cruise control transducer, engagement switch and servo; turn signal switch, wiper delay switch and controller, wiper/washer controller and pump, power sunroof / convertible top motor and switches, relays, gauges, electronic level control module, instrument cluster, electronic mixture control unit and sensors, electronic anti-detonation sensors, keyless entry system, and electronic anti-theft device (factory installed only).

Braking Components: Master cylinder, power assist booster, wheel cylinders, combination valves, metal hydraulic lines and fittings, disc calipers, backing plates, springs, clips, retainers, and electronic anti-lock brake system (ABS) and relays. Parking brake linkage and cables, and rear actuators.

Steering Components: Gear housing and all internally lubricated parts, including the rack and pinion, power steering pump, main and intermediate shafts. Couplings, cooler and cooler lines, power cylinder and pitman arm. Idler arm, tie rod and tie rod ends and control valve.

Maximum

Includes Preferred components plus:

All Parts (Exclusionary): Maximum Plan covers all parts of the vehicle except for parts listed under the Exclusions from Coverage section of the agreement, parts covered under the manufacturer's warranty, special policy, or recall; and Seals & gaskets failures unless coverage option was selected on YOUR DECLARATION PAGE.

This brochure is for marketing purposes only. Please see your agreement for complete terms, coverage, and exclusions.

Prosidium Warranty & Capital

8790 E Via De Ventura #4427
Scottsdale, AZ 85258-9998

prosidiumusa.com

For Assistance:

866-330-6117
E: claims@pwcteam.com

US-FJ-PLC-DB-A-7.2025

For Roadside Assistance:

877-211-8136

